


Assembly Instructions

For SeaAira Adirondack Chair

Tools Needed: hammer, 7/16" wrench, #2 square bit screw driver or power driver, No drilling is required. All the necessary holes are predrilled. Bolts fit snugly in the holes. You may need to use a hammer to drive the bolts through the holes.



Parts



Step 1 — Fasten back assembly to seat assembly



Place the seat assembly on a clean, flat work surface. Place the two spacer blocks close to the side rails of the seat assembly where the back attaches. Set the back on top of the space blocks. Push the back into the seat against the back seat slat. Fasten with the four 2 $\frac{1}{2}$ " screws using the pilot holes in the seat side rail.

Step 2 — Attach legs to seat assembly

4 - 2 3/4 " Carriage bolts with nuts, 2 leg assemblies





Push carriage bolts through the holes in the leg assembly. Set seat on edge. Fit the leg assembly onto the side of the seat. Tap the bolt heads with a hammer to set them firmly against the leg. Place the nuts on the bolts and tighten securely.

Repeat for the other leg assembly

Step 3 — Secure arms to back assembly

2 – 3" Lag bolts with washers, 2 arms, back assembly



Place a washer on a 3" lag and fasten the back of the arm to the back of the chair. Be sure to place the lag in the pilot hole in the chair back.

Congratulations! Your SeaAira Adirondack Chair is ready to enjoy!

